

INSTALLATION INSTRUCTIONS

1. Be sure the subfloor surface is clean and dry.*
2. Roll Quiet Walk underlayment over the subfloor with the vapor barrier film (logo imprinted side) facing up to allow the laminate flooring to slide easily over the surface.
3. The perimeter edges of Quiet Walk need to be 1/2 to 3/4 inches away from the wall.
4. Seams need to be butted together flush, do not overlap the pad. Tape the seams with duct tape.
5. Install laminate flooring according to the manufacturer's installation instructions.



* In geographic areas where concrete slabs are subject to excessive moisture, a calcium chloride moisture test is recommended. Vapor emission readings in excess of 3 lbs. per 1,000 square feet in 24 hours may require additional protection such as a concrete sealant or polyethylene sheeting.

NOTE: All rolls of QuietWalk are cut to a minimum of 100 square feet. The average thickness of QuietWalk is .125 of an inch. The average weight of a roll is 11.5 lbs.