

# Door Sweeps

## INSTALLATION INSTRUCTIONS

- 1 Measure and cut sweep to fit.
- 2 Close door. Hold sweep making gentle contact with the threshold.
- 3 Mark screw holes. Drill holes using #31 or 3.048mm drill bit.
- 4 Install with screws provided.
- 5 Adjust sweep position to make proper contact with the threshold, allowing smooth operation of the door.



### **ZERO INTERNATIONAL**

415 Concord Avenue, Bronx, NY 10455-1004

Tel : 718-585-3230 • Fax : 718-292-2243

[Zero.Customer.Support@allegion.com](mailto:Zero.Customer.Support@allegion.com)

[www.zerointernational.com](http://www.zerointernational.com)

