

1. FOR HEAT WELDING LAPS USE 1 1/2" WELD WITH AUTOMATIC MACHINE WELDER.

2. FOR INSULATION THICKNESS GREATER THAN 8" CONTACT GAFMC CONTRACTOR SERVICES FOR ALTERNATE MEMBRANE ATTACHMENT REQUIREMENTS.

3. APPLY EVERGUARD[®] TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).

		PLATE & FASTENER PLACEMENT DETAIL	drawing #	system MA
ww.gaf.com 361 Alps Rd. yne, NJ 07470	FIELD OF ROOF SERIES		scale N.T.S.	ISSUE/ REVISION DATE 7-01-11