



Right to site.

IO&M

Wall and Door Protection - 10.26.00

Lexan Corner Guard

1. Locate and install Lexan Corner Guard in accordance with architectural drawings and specifications.
2. All materials shipped unassembled. Store vertically or on flat horizontal surface. Check the material for any damage that may have occurred during shipment and/or handling at job site.
3. Begin installation only after finish construction has been completed and building interior has been within temperature range intended for continued use for at least 24 hours. Prior to installation, allow Corner Guards to reach room temperature.
4. Lay out work to be completed at the base of the substrate.
5. Inspect wall corners to confirm sound construction and repair if necessary. Make sure the wall where corner guards are to be attached is smooth and clean so the corner guard will fit tight against the corner. Any surface defects will show through the clear Lexan corner guards.
6. Place the corner guard in position. Secure in position through pre-drilled holes with mounting screws.
Note: Lexan corner guards are available with double sided tape. It is imperative that the walls be completely smooth and clean for tape to adhere. Failure to properly prepare the walls may negate the warranty
7. Remove protective covering from corner guards and clean as necessary