

INSTALLATION INSTRUCTIONS NON-RATED FLUSH ACCESS PANELS

Series NT or MT panel has an exposed 1" flange.

Series NW or MW panel has a drywall bead flange.

Series NP or MW panel has casing bead with metal lath attached at the frame. (Metal lath excluded on panels greater than 24"x 24" in size.)

Wall or ceiling is door size plus 1/4". ie: for 12"x12" door, opening should be 12-1/4" x12-1/4".

Place panel into opening. For series NP, install panel before plastering. For series NT or NW, flange should butt firmly against drywall ceiling.

With door in open position, provide anchor attachments through predrilled holes in frame into framing material. (Attachment hardware is not included). For masonry or concrete use expansion anchors.

Check panel for freedom of movement. Shim frame to adjust to square.

For series NW or MW, run drywall screws through drywall bead approximately every 8". Tape and mud flange in. For series NP or MP, plaster up to exterior of frame of panel.

For maximum resistance to corrosion, latex or enamel paint should be applied.