

Wiremold® WSM Series Grommet

Installation Instructions No: 1 010 853 - 0312

Catalog Number(s): WSMSTCBK, WSMSTCSL, WSMSTCWH, WSMSDTCBK, WSMSDTCSL, WSMSDTCWH,

WSCSTCBK, WSCSDTCBK, WSCSTCSL, WSCSDTCSL, WSMEUTBK, WSMEUTSL, WSMEDUTBK, WSMEDUTSL, WSCEDUTBK, WSCEDUTSL, WSCEDUTBK, WSCEDUTSL,

Single Portal Kits: WSMEDTC72SLSK, WSMEDTC60SLSK, WSMEDTC72BKSK,

WSMEDTC60BKSK

Double Portal Kits: WSMEDTC72SLDK, WSMEDTC60SLDK, WSMEDTC72BKDK,

WSMEDTC60BKDK

Country of Origin: Made in U.S.

• READ ALL INSTRUCTIONS BEFORE BEGINNING

- 1. Provide 5.25" x 3" [133mm x 76mm] cutout at location Grommet will be mounted.
- 2. Install Grommet into cutout; be sure Grommet is fully seated.
- Insert mounting screws (not included) through Grommet mounting holes and into work surface as shown

Legrand/Wiremold electrical systems conform to and should be properly grounded in compliance with requirements of the current National Electrical Code or codes administered by local authorities.

All electrical products may present a possible shock or fire hazard if improperly installed or used. Legrand/Wiremold electrical products may bear the mark of a Nationally Recognized Testing Laboratory and should be installed in conformance with current local and/or the National Electrical Code.



