

# Floor HEAT Mat

**0800 Series** 

DS-605.0-0707



## 1. PRODUCT NAME

LATICRETE® Floor HEAT Mat

## 2. MANUFACTURER

LATICRETE International, Inc. 1 LATICRETE Park North Bethany, CT 06524-3423 USA

> Telephone: 203.393.0010, ext. 235 Toll Free: 800.243.4788, ext. 235

Fax: 203.393.1684 Internet: www.laticrete.com

# 3. PRODUCT DESCRIPTION

LATICRETE Floor HEAT Mat is a versatile floor warming mat designed to be installed underneath tile and stone floors to provide luxury and comfort. The product includes adhesive backing for easy installation.

All electrical connections must be made by a licensed electrician. Failure to do so will void all warranties and claims. Comply with all applicable building and electrical codes.

## **Advantages**

- Component of LATICRETE 10 Year System Warranty, LATICRETE Lifetime Residential Warranty and LATICRETE 15 Year Residential Warranty
- Self-adhesive mesh backing
- Intertwined heating element and mesh construction
- UL approved

# Suitable Substrates (Interior Dry Area Only)

- Concrete
- Mortar Beds
- Exterior Glue Plywood\*
- Existing Ceramic Tile and Stone
- Cement Terrazzo
- Cement Backer Board
- Over TCNA approved constructs using plastic lath when using portland cement based self-leveling underlayments.

#### Limitations

- Interior floor installations only.
- Not for use in showers, tubs or steam rooms.
- Adhesives/mastics, mortars and grouts for ceramic tile, pavers, brick and stone are not replacements for waterproofing membranes. When a waterproofing membrane is required use a LATICRETE Waterproofing Membrane (see Section 10 FILING SYSTEMS).
- Note: Surfaces must be structurally sound, stable and rigid enough to support ceramic/stone tile, thin brick and similar finishes. Substrate deflection under all live, dead and impact loads, including concentrated loads, must not exceed L/360 for thin-bed ceramic tile/brick installations or L/480 for thin-bed stone installations where L=length of span.

#### **Cautions**

Consult MSDS for more safety information.

- Do not turn LATICRETE Floor HEAT on until entire installation of tile and grout has fully cured.
- During cold weather, protect finished work from traffic until fully cured.
- · Keep out of reach of children.
- Do not staple heating elements directly.
- Do not allow LATICRETE Floor HEAT to come into contact with water or moisture.
- Use only appropriate size of LATICRETE Floor HEAT for specified area of floor to be heated. DO NOT TUCK/INSTALL/ FOLD EXCESS MAT INTO WALL CAVITY.

# 4. TECHNICAL DATA

# 120 VAC Standard Mat Specifications (Mat Only)

Product (W x L)	Sq. Ft.	Model Number	Watts	Amps	Ohms
1' X 10'	10'	0800-1210-2	150	1.3	96
1' X 12'	12'	0800-1212-2	180	1.5	80
1' X 15'	15'	0800-1215-2	225	1.9	64
1' X 20'	20'	0800-1220-2	300	2.5	48
1' X 23'	23'	0800-1223-2	345	2.9	42
1' X 25'	25'	0800-1225-2	375	3.1	38
1' X 30'	30'	0800-1230-2	450	3.8	32
1' X 35'	35'	0800-1235-2	525	4.4	27
1' X 40'	40'	0800-1240-2	600	5.0	24
1' X 45'	45'	0800-1245-2	675	5.6	21
1' x 50'	50'	0800-1250-2	750	6.3	19
1.5' x 37'	55.5	0800-1837-2	832.5	6.9	17

# 120 VAC Standard Mat Specifications (Mat Only) continued

Product (W x L)	Sq. Ft.	Model Number	Watts	Amps	Ohms
1.5' X 40'	60'	0800-1840-2	900	7.5	16
1.5' X 44'	66'	0800-1844-2	990	8.3	15
1.5' X 47'	70.5	0800-1847-2	1057.5	8.8	14
1.5' X 50'	75'	0800-1850-2	1125	9.4	13
1.5' X 54'	81'	0800-1854-2	1215	10.1	12
3' x 2'	6'	0800-3602-2	90	0.8	160
3' x 5'	15'	0800-3605-2	225	1.9	64
3' x 7'	21'	0800-3607-2	315	2.6	46
3' x 30'	90'	0800-3630-2	1350	11.3	11

# 240 VAC Standard Mat Specifications (Mat Only)

Product (W x L)	Sq. Ft.	Model Number	Watts	Amps	Ohms
1.5' X 13'	19.5'	0800-1813-4	292.5	1.2	197
1.5' X 20'	30'	0800-1820-4	450	1.9	128
1.5' X 27'	40.5'	0800-1827-4	607.5	2.5	95
1.5' X 33'	49.5'	0800-1833-4	742.5	3.1	78
1.5' X 40'	60'	0800-1840-4	900	3.8	64
1.5' X 47'	70.5	0800-1847-4	1057.5	4.4	54
1.5' X 53'	79.5	0800-1853-4	1192.5	5.0	48
3' x 30'	90'	0800-3630-4	1350	5.6	43
3' x 35'	105'	0800-3635-4	1575	6.6	37
3' x 40'	120'	0800-3640-4	1800	7.5	32
3' x 45'	135'	0800-3645-4	2025	8.4	28
3' x 50'	150'	0800-3650-4	2250	9.4	26

## 5. INSTALLATION

Please refer to LATICRETE® Floor HEAT Installation Instructions DS 605.9.

## 6. AVAILABILITY AND COST

# **Availability**

LATICRETE Floor Warming products are available in North America. For distributor information:

Toll Free: 800.235.4788
Telephone: 203.393.0010
Internet: www.laticrete.com

Cost

Contact a LATICRETE Distributor in your area.

# 7. WARRANTY

See 10. FILING SYSTEM

DS 230.13: LATICRETE Product Warranty

A component of:

DS 230.12: LATICRETE 10 Year System Warranty
DS 230.14: LATICRETE 15 Year Residential Warranty
DS 700.12: LATICRETE Lifetime Residential Warranty

#### 8. MAINTENANCE

Following installation, the LATICRETE Floor HEAT Mat does not require any maintenance.

#### 9. TECHNICAL SERVICES

## **Technical assistance**

Information is available by calling:

Toll Free: 800.243.4788, ext. 235 Telephone: 203.393.0010, ext. 235

Fax: 203.393.1948

To acquire technical and safety literature, please visit our website at www.laticrete.com.

#### 10. FILING SYSTEM

DS 230.13: LATICRETE Product Warranty

DS 230.12: LATICRETE 10 Year System Warranty
DS 230.14: LATICRETE 15 Year Residential Warranty
DS 700.12: LATICRETE Lifetime Residential Warranty

DS 604.0: LATICRETE Wire Eye™

DS 606.0: LATICRETE Floor Warming Thermostat
DS 606.6: LATICRETE Floor Warming Thermostat

Installation Instructions

DS 236.0: LATICRETE 9235 Waterproofing Membrane DS 605.9: LATICRETE Floor HEAT Installation Manual

LATICRETE INTERNATIONAL, INC. One LATICRETE Park North Bethany, CT 06524-3423 USA 800.243.4788 203.393.0010 www.laticrete.com

©2007 LATICRETE INTERNATIONAL, INC.
LATICRETE, LATIAPOXY and the [EM] logo are Registered Trademarks of LATICRETE International, Inc.