


Data Sheet MANUAL SHADE EDGE GAPS



Bracket	A Control End	B Linking Bracket	C Idle End
R8	9/16"	N/A	9/16"
R16/R24 for 1.5" tube	5/8"	1/2"	5/8"
R16/R24 for 2" & 2.5" tube	3/4"	5/8"	5/8"
Dual bracket	3/4"	N/A	5/8"

Edge gap is the distance between the edge of the fabric panel and the edge of the window jamb.