


EJ-NBF Series

Expansion joint cover for floors
Floor to floor condition



Dimension Chart										
Model	Joint Opening (J.O.)						Total movement		S.W. at install	
	at install		allow min.		allow max.					
	inches	mm	inches	mm	inches	mm	inches	mm	inches	mm
EJ-NBF-100	1	25	0	0	2	38	2	51	3 1/2	89
EJ-NBF-200	2	51	1	25	3	76	2	51	4 1/2	114

Note: J.O. minimum and maximum values are after thermal movement occurs.



Right to site.

Call: 800-547-2635 Fax: 800-317-8770
 USA or Canada
 Web: www.nystrom.com
 E-mail: info@nystrom.com

PROJECT:

CONTRACTOR:

ARCHITECT:

INITIALS: QTY: DATE: PART NUMBER: