



Wiremold

# Desktop Power Center INSTALLATION INSTRUCTIONS


Installation Instruction No.: 1 009 456 – August 2010

PART NUMBERS: WSC320-S, WSC400-S, WSR320-S, WSR400-S


NOTE: Part Numbers WSR320-S and WSR400-S are for residential use only.

## HOLE MOUNT


Step 1. Remove Mounting Plate (A) from Power Unit (B).



Step 2. Insert Hole Mount (C) into Mounting Plate (A) and into Desk.



Step 3. Secure to Desk.



Legrand/Wiremold electrical systems conform to and should be properly grounded in compliance with requirements of the current National Electrical Code or codes administered by local authorities.

All electrical products may present a possible shock or fire hazard if improperly installed or used. Legrand/Wiremold electrical products may bear the mark as UL Listed and/or Classified and should be installed in conformance with current local and/or the National Electrical Code.

## WARNING!


READ AND UNDERSTAND ALL INSTRUCTIONS.

Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.


SAVE THESE INSTRUCTIONS

1. Grounded electrical products must be plugged into an outlet that is properly installed and grounded in accordance with all codes and ordinances. Never remove the grounding prong or modify the plug in any way. Do not use any adapter plugs. Check with a qualified electrician if you are in doubt as to whether the outlet is properly grounded.
2. Do not expose this product to rain, wet or damp conditions. Water entering this product will increase the risk of electric shock.
3. Do not abuse the power cord. Keep the power cord away from heat, oil, sharp edges, or moving parts. If power cord becomes damaged, replace the product.
4. This product must be properly installed before connecting to the power supply
5. Do not use this product in combination with an extension cord.

Step 4. Feed Power Cord through Hole. Mount and hook front slots (A) of Power Unit to Mount Clips (B).




Step 5. Attach Power Unit to Mount.




## EDGE MOUNT

**Step 1.** Remove Mounting Plate (A) from Power Unit (B).




**Step 2.** Remove Hole Mount (C).


**NOTE:** This part is not needed for edge mounting.




**Step 3.** Assemble Edge Mount (D).



**Step 4.** Attach Edge Mount to Desk.



**Step 5.** Attach Power Unit to Mount.



**legrand**<sup>®</sup>

**Wiremold**

**Wiremold**

**U.S. and International:**

60 Woodlawn Street • West Hartford, CT 06110

1-800-621-0049 • FAX 860-232-2062 • Outside U.S.: 860-233-6251

**Canada:**

570 Applewood Crescent • Vaughan, Ontario L4K 4B4

1-800-723-5175 • FAX 905-738-9721

