

Protect Your Property From Deer With Deer BlockerTM Fence



Deer Blocker Fencing - The best in the business

- 4" square mesh made from 36-ply, UV resistant high density polyethylene.
- Each strand has a knotted breaking strength of 175 pounds.
- Deer Blocker is a full 8ft high fence and is available in 100 and 300ft lengths.
- Very discreet, nearly invisible at short distance, low visual impact on property.
- Lighter, less expensive and easier to install than similar size metal or wood fences.
- 5/8" HD border woven into all edges eliminates need for top or bottom support.



EZ-Set Angle Posts - Economical deer fence posts

No overhead post driving. Strong angle iron posts install quickly.

Includes 1-4ft Ground Post, 1-8ft Top Post and 2 bolts, washers & nuts. Set up: drive ground post 2ft into the ground (½ way) with Post Driver (see accessories). Bolt Top Post to Ground Post with the included hardware.

Space posts between 10 to 20 ft along the perimeter of the Deer Blocker enclosure.




Premium Posts - Premium round tube deer fence posts

No overhead post driving. System can be removed quickly if needed.

Includes 1-Premium post (1.6" black round tube) with cap and 1-Ground Sleeve.

Set up: use the Sleeve Driver (see accessories) to drive ground sleeve flush to the ground. Install the Premium Post into the Ground Sleeve.

Space posts between 10 to 20 ft along the perimeter of the Deer Blocker enclosure.



Deer Blocker Fence Hardware & Accessories

Ground Stakes: 12" long galvanized steel stakes secure bottom edge of fencing.

Ground Anchor: 17" long steel screw-in anchors to reinforce corner posts.

Post Driver: Sets EZ-Set Angle Posts quickly. Protects your post and your fingers. **Sleeve Driver:** Steel plug used to install Ground Sleeve. Protects Sleeve from damage.

Net Ties: 7.5", 11.5", 14.5" UV MIL-Spec ties fasten fencing to posts. 100 or 1,000 ct bags. **Repeller Ribbon:** Cut into strips and tied to the fence for 'flagging' - see back page.

More Deer Blocker Fence Details On Back

Questions? Contact Nixalite - we can help design your Deer Blocker Enclosure Nixalite® of America Inc P 800.624.1189 F 800.624.1196 www.nixalite.com

Why Use Deer Blocker?

Deer Problem:

Over development of rural areas forces wild deer into urban areas, leading to unexpected and unwelcome problems and conflicts.

- Deer can ruin landscaping, trees, seedlings and gardens.
- Deer parasites carry Lyme disease, Tularemia, Rocky Mountain Fever, etc.
- Deer can transmit diseases and parasites to you, your pets and livestock.
- Deer vs. auto accidents kill and injure thousands of people every year.

Deer Blocker Solution:

A Deer Blocker Fence enclosure provides a humane and discreet barrier that keeps deer out of sensitive areas without relying on chemicals or electricity.

- Protects everything from small gardens to golf courses.
- Keeps deer separated from livestock, horses, pets, etc.
- Can help in keeping deer away from busy roads and trails.


Why Deer Blocker Is Superior:

Deer Blocker is the best in the business because it offers the best value. It is long lasting, lightweight, very strong and easy to install. The 4" square mesh is nearly invisible and has very little wind loading. It is MANY times less expensive and less conspicuous than an all metal or wood fence.

Protect:

- Landscaping
- Nurseries
- Trees, shrubs
- Lawns, gardens
- Orchards
- Vineyards
- Sod farms
- Municipal parks
- Golf courses
- Cemeteries
- Ball fields
- Busy roads
- •Livestock pens
- Stables, barns
- Grain storage
- Many more

Deer Blocker Installation Guidelines



Use Deer Blocker Fence to protect your entire property or just selected areas within it. Be sure to completely enclose the area to be protected.

Accurately measure perimeter of the enclosure. Note any trees or existing objects that could be used to support the fence. Deer Blocker Fence must be supported every 10 to 20 feet. If existing trees and objects are too far apart, install additional posts to maintain this spacing. If trees or objects are not available, use our Deer Fence posts for the entire enclosure.

To install Nixalite's Deer Fence posts, use the instructions included with the post. If needed, reinforce corner posts with a cable and anchor system.

Fasten the fence to existing supports with u-nails, staples, etc. Secure the fence every 12" along the support (from top to bottom). Pull the fence tight and fasten to the next support.

Fasten the fence to Nixalite posts with Net Ties. Secure the fence every 12" along the post (from top to bottom). Pull the fence tight and fasten to the next post or support.

To prevent deer from pushing under the fence, stake the bottom edge of the fence to the ground every 3 to 4 feet using Nixalite's Ground Stakes.

IMPORTANT. Attach 2ft long strips of Repeller Ribbon to the fence. Space them every 10 ft along the fence, 4ft up from the ground. This makes the fence more visible to deer (day and night) and helps prevent collisions. Add ribbon to any corner cables as well.

If you have any questions about the Deer Blocker Fencing, posts or any other detail, please contact Nixalite.



Phone: 800.624.1189 or 309.755.8771

Fax: 800.624.1196 or 309.755.0077

Email: birdcontrol@nixalite.com

Web: www.nixalite.com

Where the World Shops for Humane Bird and Animal Control.