



Vinyl Recess Mount Corner Guard
Models: BCGVR2S, BCGVF2S, BCGVR3S and BCGVF3S

1. Cut retainer (with base attached) to full height. Install optional top cap clinching in place at top of retainer. Attach continuous retainer unit to corner using appropriate fasteners at 18" (457.2mm) O.C. maximum.
2. Finish walls to specification, taping and spackling over retainer flanges. Install wallcovering or paint as specified.

Note: Fire Protection must not be interrupted for full height of corner. Fire-rated partition must close-off and continue above top of corner guard.



3. Snap precut cover in position. Cover should be lipped over one edge and pressure applied toward opposite leg from center with a "snap action" movement. Procedure should begin at bottom and be repeated as necessary for full height of cover.
4. Contact your Babcock-Davis representative for information on replacement parts



Maintenance:

1. Use mild detergent to clean soiled surfaces. Do not use powdered cleansers, bleach and ammonia-based cleaners as they may leave a residue embedded in the cover surface. Pen marks, paint and graffiti generally wash off easily with mild soap and water. Completely rinse the surface with clean water when complete.
2. Tough marks or stains may require a heavy duty cleaner such as "Crown Anti-Vandal Spray" or "DWR-II". These specialized spot cleaners should only be used on small areas and tested for color fastness prior to applying in a highly visible area. Rinse thoroughly with clean water to remove the residue from these cleaners