

Insulation Fact Sheet

| Insulation Thickness (inches) | R-value per ASTM 518 Aged Values | | | | |
|-------------------------------------|----------------------------------|--------------------------|--------------------------|---------------------------|------------------------|
| | Bayseal [®] OC | Bayseal [®] OCX | Bayseal [®] CCX | Bayseal [®] CCXP | EcoBay [®] CC |
| | | | | | |
| 1 | 3.7 | 3.9 | 6.9 | 6.9 | 6.9 |
| 3.5 | 13 | 13 | 24 | 24 | 24 |
| 5.5 | 20 | 20 | 38 | 38 | 38 |
| 7.5 | 26 | 26 | 52 | 52 | 52 |
| 10 | 35 | 36 | 69 | 69 | 69 |
| 12 | 42 | 43 | 83 | 83 | 83 |
| 16 | 56 | | | | |
| | Read This Before You Buy | | | | + |

The chart shows the R-value of this insulation. R means resistance to heat flow. The higher the R-value, the greater the insulating power. Compare insulation R-values before you buy. There are other factors to consider. The amount of insulation you need depends mainly on the climate you live in. Also, your fuel savings from insulation will depend upon the climate, the type and size of your house, the amount of insulation already in your house, and your fuel use patterns and family size. If you buy too much insulation, it will cost you more than what you will save on fuel. To get the marked R-value, it is essential that this insulation be installed properly.

Manufacturer:

Covestro LLC 2400 Spring Stuebner Road Spring, TX 77389 1.800.221.3626 Tel 281.350.9000 Fax 281.288.6450 www.covestro.com/sprayfoam