

Features

- Excellent durability
- Excellent flow and leveling properties
- · Extended open time
- Spatter resistant
- Easy application
- Easy clean up
- Block resistant

ADVANCE[®] WATERBORNE INTERIOR ALKYD SEMI-GLOSS 793

General Description

A premium quality, waterborne alkyd enamel that delivers the desired flow and leveling characteristics of conventional alkyd paint. It provides a tough, Semi-Gloss finish that stands up to repeated washing. It is easy to apply, resists spattering and cleans up with soap and water.

Recommended For

Ideal for interior doors, trim, cabinets, walls, and ceilings. For primed or previously painted wallboard, plaster, masonry, wood and metal.

Limitations

- Proper adhesion to existing enamel, catalyzed lacquers or synthetic surfaces will require sanding and priming with a specialty primer. See Primer/Finish Systems on page 2.
- Depending on weather and drying conditions, it could take up to 30 days to reach optimum hardness and final sheen.

Product Information			
Colors — Standard:		Pastel Base	
White (01)	Vehicle Type	Waterborne alkyd	
	Pigment Type	Titanium Dioxide	
— Tint Bases:	Volume Solids	37.1%	
Benjamin Moore [®] Gennex [®] Bases 1X, 2X, 3X, 4X	Coverage per Gallon at Recommended Film Thickness	400 – 500 sq. ft.	
— Special Colors:	Recommended Film – Wet Thickness – Dry	3.6 mils 1.3 mils	
Contact your Benjamin Moore representative. Certification:	Depending on surface texture and porosity. Be sure to estimate the right amount of paint for the job. This will ensure color uniformity and minimize the disposal of excess paint. See chart on page two.		
VOC compliant in all regulated areas	Dry Time @ 77°F – To Touch (25°C) @ 50% RH – To Recoat	4-6 Hours 16 Hours	
Class A (0-25) over non-combustible surfaces when tested in accordance with ASTM E-84	Advance's full hardness and adhesion develop over time. Do not expose to heavy abrasion or return shelves/tabletops to service for at least 3-5 days to prevent damage to the finish. High humidity or cooler temperatures will prolong dry, recoat and cure times.		
Qualifies for (Collaboration for LEED [®] High	Dries By E	vaporation, Oxidation	
Credit Performance	Viscosity	95 ± 2 KU	
(INTERIOR NON-FLAT Schools) FOR SCHOOLS)	Flash Point	None	
	Gloss / Sheen Semi-Gloss (50-60 @ 60°)		
Technical Assistance: Available through your local authorized independent Benjamin Moore [®]	Surface Temperature – Min. at Application – Max	50°F 90°F	
retailer. For the location of the retailer nearest you, call 1-800-826-2623, see www.benjaminmoore.com, or consult your local Yellow Pages.	Thin With	Clean Water	
see www.benjamininoore.com, or consult your local reliow Pages.	Clean Up Thinner	Clean Water	
	Weight Per Gallon	10.8 lbs	
	Storage Temperature - Min - Max	40°F 90°F	
	Volatile Organic Compounds (VOC)		
	48 Grams / Liter .40 LBS / Gallon		

 $\Diamond \mbox{Reported values are for Pastel Base. Contact Benjamin Moore for values of other bases or colors$

Surface Preparation

Surfaces to be painted must be clean, dry, and free of dirt, dust, grease, oil, soap, wax, scaling paint, water soluble materials, and mildew. Remove any peeling or scaling paint and sand these areas to feather edges smooth with adjacent surfaces. Glossy areas should be dulled. Drywall surfaces must be free of sanding dust.

New plaster or masonry surfaces must be allowed to cure before applying base coat. Cured plaster should be hard, have a slight sheen and maximum PH of 10; soft, porous or powdery plaster indicates improper cure. Never sand a plaster surface; knife off any protrusions and prime plaster before and after applying patching compound. Poured or pre-cast concrete with a very smooth surface should be etched or abraded to promote adhesion, after removing all form release agents and curing compounds. Remove any powder or loose particles before priming. Wood substrates must be thoroughly dry.

Difficult Substrates: Benjamin Moore offers a number of specialty primers for use over difficult substrates such as bleeding woods, grease stains, crayon markings, hard glossy surfaces, galvanized metal, or other substrates where paint adhesion or stain suppression is a particular problem. Your Benjamin Moore retailer can recommend the right problem solving primer for your special needs.

WARNING! If you scrape, sand or remove old paint, you may release lead dust. LEAD IS TOXIC. EXPOSURE TO LEAD DUST CAN CAUSE SERIOUS ILLNESS, SUCH AS BRAIN DAMAGE, ESPECIALLY IN CHILDREN. PREGNANT WOMEN SHOULD ALSO AVOID EXPOSURE. Wear a NIOSH-approved respirator to control lead exposure. Carefully clean up with a HEPA vacuum and a wet mop. Before you start, find out how to protect yourself and your family by contacting the National Lead Information Hotline at 1-800-424-LEAD or log on to www.epa.gov/lead

Primer/Finish Systems

New surfaces should be fully primed, and previously painted surfaces may be primed or spot primed as necessary. For best hiding results use Benjamin Moore® Advance® Waterborne Interior Alkyd Primer tinted to the approximate finish coat color. Special Note: Certain custom colors require a Deep Color Base Primer tinted to a special prescription formula to achieve the desired color. Consult your retailer.

Wood and engineered wood products:

Primer: Advance® Waterborne Interior Alkyd Primer (790), Fresh Start® All-Purpose 100% Acrylic Primer (N023), Fresh Start®100% Acrylic Superior Primer (046) or Fresh Start® All-Purpose Alkyd Primer (024)

Finish: 1 or 2 coats Advance® Waterborne Interior Alkyd Semi-Gloss (793)

Cabinetry-All surfaces to be roughened by sanding (220 grit or coarser) before priming; light sanding between coats allows for a smoother finish; all dust must be cleaned.

Wood, MDF & Thermofoil

Primer: 1 coat Advance® Waterborne Interior Alkyd Primer (790)

Finish: 1 or more coats of Advance® Waterborne Interior Alkyd Semi-Gloss (793)

Laminate (Formica)

Primer: 1 coat Fresh Start® 100% Acrylic Superior Primer (046) Finish: 1 or more coats of Advance® Waterborne Interior Alkyd Semi-Gloss (793)

Plastic (Vinyl) veneer

Primer: 1 coat of Advance[®] Waterborne Interior Alkyd Primer (790) after removing plastic veneer by sanding away (an electric sander with a 100 grit paper works fine; manual sanding may need to be vigorous) Finish: 1 or more coats of Advance® Waterborne Interior Alkyd Semi-Gloss

(793)

Drywall:

Primer: Advance® Waterborne Interior Alkyd Primer (790)

Finish: 1 or 2 coats Advance[®] Waterborne Interior Alkyd Semi-Gloss (793)

Plaster:

Primer: Fresh Start® All-Purpose 100% Acrylic Primer (N023) or Fresh Start®100%

Acrylic Superior Primer (046) Finish: 1 or 2 coats Advance[®] Waterborne Interior Alkyd Semi-Gloss (793)

Rough or Pitted Masonry:

Primer: Super Spec® Latex Block Filler (160) or Super Spec® Masonry Interior/Exterior Hi-Build Block Filler (206)

Finish: 1 or 2 coats Advance® Waterborne Interior Alkyd Semi-Gloss (793)

Smooth Poured or Pre-cast Concrete:

Primer: Fresh Start® All-Purpose 100% Acrylic Primer (N023) or Fresh Start®100% Acrylic Superior Primer (046)

Finish: 1 or 2 coats Advance[®] Waterborne Interior Alkyd Semi-Gloss (793)

Ferrous Metal (Steel and Iron):

Primer: Super Spec HP® Acrylic Metal Primer (P04) or Super Spec HP® Alkyd Metal Primer (P06)

Finish: 1 or 2 coats Advance® Waterborne Interior Alkyd Semi-Gloss (793)

Non-Ferrous Metal (Galvanized & Aluminum): All new metal surfaces must be thoroughly cleaned with Super Spec HP[®] Oil & Grease Emulsifier (P83) to remove contaminants. New shiny non-ferrous metal surfaces that will be subject to abrasion should be dulled with very fine sandpaper or a synthetic steel wool pad to promote adhesion **Primer:** Super Spec HP[®] Acrylic Metal Primer (P04) or Super Spec HP[®]

TIM Acrylic Low Lustre (P25) Finish: 1 or 2 coats Advance® Waterborne Alkyd Semi-Gloss (793)

Repaint, All Substrates: Prime bare areas with the primer recommended for the substrate above.

Application

Stir thoroughly before and during use. Apply one or two coats. Paint Application: For best results, use a premium Benjamin Moore® customblended nylon/polyester brush, premium Benjamin Moore® Microfiber roller, or a similar product. Apply paint generously from unpainted area into wet area. This product can also be spraved.

Extra ventilation is necessary under humid conditions to speed the dry time of Advance, especially when the paint is applied over sealed, hard, non-porous surfaces. The chart below is for general guidance.			
Mild conditions	Severe conditions	Very severe conditions	
Dry (RH<50%), and Temperature between 70°F and 90°F	(RH> 50%), and/or temperature between 50°F and 70°F	RH> 85%, or temperature < 50°F	
Advance will dry normally. Dry to touch: 4-6 hours To Recoat: 16 hours	Advance will dry slower than normal unless the following is done to speed the dry time: Ventilate the room with a fan and/or turn on A/C to lower the humidity.	Do not apply Advance	

Spray, Airless:

Fluid Pressure — 1,500 - 2,500 PSI; Tip — .011 - .015 Orifice

Thinning/Cleanup

Thinning is unnecessary, but if required to obtain desired application properties, a small amount of clean water may be added. Never add other paints or solvents. Clean up with warm soapy water. Brushes and rollers should be given a final rinse with mineral spirits to remove residual alkyd. Spray equipment should be given a final rinse with mineral spirits to prevent rusting

USE COMPLETELY OR DISPOSE OF PROPERLY. Dry, empty containers may be recycled in a can recycling program. Local disposal requirements vary; consult your sanitation department or state-designated environmental agency on disposal options.

Environmental Health & Safety Information

Use only with adequate ventilation. Do not breathe spray mist or sanding dust. Ensure fresh air entry during application and drying. Avoid contact with eyes and prolonged or repeated contact with skin. Avoid exposure to dust and spray mist by wearing a NIOSH approved respirator during application, sanding and clean up. Follow respirator manufacturer's directions for respirator use. Close container after each use. Wash thoroughly after handling.

WARNING: This product contains a chemical known to the state of California to cause cancer and birth defects, or other reproductive harm.

FIRST AID: In case of eye contact, flush immediately with plenty of water for at least 15 minutes; for skin, wash thoroughly with soap and water. If symptoms persist, seek medical attention. If you experience difficulty breathing, leave the area to obtain fresh air. If continued difficulty is experienced, get medical attention immediately.

IN CASE OF SPILL - Absorb with inert material and dispose of as specified under "Clean Up"

KEEP OUT OF REACH OF CHILDREN PROTECT FROM FREEZING **Refer to Material Safety Data Sheet for** additional health and safety information.

Benjamin Moore & Co., 101 Paragon Drive, Montvale, NJ 07645 Tel: (201) 573-9600 Fax: (201) 573-9046 www.benjaminmoore.com M72 793 US 110911 Advance, Benjamin Moore, Fresh Start, Gennex, Super Spec, Super Spec HP and the triangle "M" symbol are registered trademarks licensed to Benjamin Moore & Co. © 2011 Benjamin Moore & Co. All rights reserved All other trademarks belong to their respective owners.